



1. Always use a steel measuring tape as cloth tapes stretch
2. Always provide the narrowest dimension rounded down to nearest 1/8th of an inch.
3. Balcony Skylight Shades are inside mount only!
4. Sill depth required for a Shallow Mount: 1 -1/4"
5. Sill depth required for a Flush Mount: 2 -11/16"

Width:

Measure the width in three places (top, middle, bottom) and provide the narrowest dimension.

Height:

Measure the height in three places (left, center, right) and provide the narrowest dimension.

NOTE: The widest width of the window cannot exceed the narrowest width of the window by more than 3/8 of an inch or the shade will not function properly.

Shallow Mount

Shallow mount shades are installed inside the window casing where there's enough room to install the brackets but there is not enough room for the shade to be installed fully within the window frame and so part of the shade/headrail will protrude from the window frame.

Flush Mount

Flush mount is when the shade is mounted completely within the window frame and no part of the headrail/shade protrudes from the window frame.