

Inside Mount

The Blind or Shade will be mounted inside the window frame providing a clean look. Please see minimum mounting requirements to determine which option is best for your window type.

To determine the width of your inside mount treatment, take the measurements in 3 places, (top, middle and bottom) and use the narrowest dimension.

To determine the length of your inside mount treatment, take the measurement in 3 places as well, (left, middle and right) and use the longest dimension.

Please give exact inside mount measurements; we will take deductions necessary for proper inside mount operation.

Outside Mount

The Blind or Shade will be mounted outside the window frame or on the frame itself. This style should be used when there is not enough depth to mount inside the window frame. Mount to the surrounding wall, ceiling or window frame or molding.

To determine the width of your outside mount treatment, take the measurements in 3 places, (top, middle and bottom) and use the widest dimension.

If desired, you may add 1 – 1 1/2 inches on each side of the outside mount width to fully cover the window and framing and to reduce light penetration from the edges.

To determine the length of your outside mount treatment, take the measurement in 3 places as well, (left, middle and right) and use the longest dimension.

Outside mount measurements are exact and window treatments will be made to those exact specifications.

