

Measuring Instructions for Roller Shades Important Measuring Guidelines

Precise width and length measurements are critical. Fabric width cannot be altered after the shading is fabricated.

- Please use a metal tape measure for accuracy from home to factory.
- The head rail must be installed perfectly level and installed evenly to ensure smooth operation. On an inside mount, it is recommended that you check to see that the mounting surface is level and consistent. If your soffit needs to be leveled, this should be done before measuring.
- Roller Shades are leveled and weighted in the factory. When installed level, the fabric will not skew when raised. If the head rail is not installed level, skewing can occur that can damage the edge of the fabric. Be sure to follow the installation instructions carefully to ensure balanced operation.


Roller Shade Mounting Information Standard Roller

- Minimum depth for shallow inside mount including installation brackets: 1-1/4"
- Minimum depth for flush inside mount including installation brackets: 3"
- Minimum surface area for outside mount: 1/2"

Clutch Hardware Mounting Information

- Minimum Shallow Mount Depth: 1-3/4"
- Minimum Flush Mount Depth: 4"
- Surface area for outside mount: 1-1/2"

Measuring Instructions for Roller Shades



Inside Mount (IB)

Measure the width of the window at the top where the brackets will be installed and round down to the nearest 1/8 of an inch. The factory will take the necessary deductions to ensure a proper fit and a smooth operation.

Measure the length of the window opening from the underside of the soffit to the surface of the windowsill in two places - use the smallest of these two measurements.

Outside Mount (OB)

Measure the exact width and length of the area to be covered. On the width, allow at least 1-1/2" of an overlap on each side. An overlap of 3" on each side is recommended. Be sure to take into consideration any obstructions such as window trim, molding, locks and window cranks.